

UZIN U 3000

Tackifier and primer for the installation of luxury vinyl tiles

Areas of application and set introduction:

The UZIN U 3000 system is a new way for the easy and ergonomic installation of high-quality, dimensionally stable luxury vinyl tiles. The system is comprised of the quick tackifier UZIN U 3000 RollFix as well as the ready to use dispersion primer UZIN U 3000 primer. Two packaging versions are available with 125 m² as well as 60 m². The respective set includes, in addition to the Primer and Roll-Fix, the complete accessories for installation such as roller handle, application rollers and brushes. The 60 m² pack includes one-way film in addition. The outer packaging bucket can thus be used as the perfect roll-on bucket.



Substrate preparation:

- 1 The substrate must be a levelled area or a surface treated with a squeegee. Ideally, a Level Plus levelling compound such as UZIN NC 170 LevelStar or UZIN NC 110 should be used. These compounds are distinguished, amongst others, by optimal self-levelling properties and an extremely smooth surface. Particular attention must be given to sufficient drying time of the levelling compound layer (depending on the layer thickness). Briefly grind the dry levelling compound with a single-disk grinding machine and abrasive paper with grain size 40.
- 2 This is followed by thoroughly vacuuming off the ground area.



UZIN U 3000 Primer application

- 3 Prime the prepared area with UZIN U 3000 Primer. Use the supplied UZIN 25 cm / 20 mm foam roller and apply the primer thin and uniformly in crosswise fashion with a consumption of approx. 50 g/m². Adequate drying time of the primer of 30 to 45 minutes (depending on type of levelling compound) must be observed.



UZIN U 3000 RollFix application

- 4 Now apply UZIN U 3000 RollFix with the supplied UZIN 25 cm / 6 mm Nylon roller crosswise with a consumption of approx. 80 g/m². The open time should be chosen so that UZIN U 3000 RollFix is still tacky, but at least 15 min. Use the UZIN brush included with the set to pre-apply RollFix to edge zones and vertical structures (columns, door frames, etc.).



Installing the floor covering

- 5 Lay down the luxury vinyl tiles on the UZIN U 3000 RollFix dried to tackiness within the max. working time of 2 hours.



- 6 Roll out and rub in the installed luxury vinyl tiles using a heavy pressure roller and rub in the edge zones.

